

BASIC PROGRAMMING				BASIC PROGRAMMING			
DISPLAY	SETTINGS	DESCRIPTION	ACTION WITH MAGNET				
Touch Dot		Touch at Any Point in Screen Rotation	Press & Hold				
PRO			Continue Press & Hold				
bA			Continue Press & Hold				
UFP		Default Battery Type Program	Release at Desired Battery Type				
FDC		Flooded Deep Cycle	Release at Desired Battery Type				
gEI	GEL	Gell Batteries	Release at Desired Battery Type				
AgL		AGM Battery	Release at Desired Battery Type				
OPS		Optima Spiral Wound Batteries	Release at Desired Battery Type				
FSB		Standard Flooded Batteries	Release at Desired Battery Type				
HAL		Halogen Systems	Release at Desired Battery Type				
bEL	b-4	Wait until scroll comes back to bEL	Press & Hold bEL> Release at b-4				
dSP	Sd	Wait until scroll comes back to dSP	Press & Hold dSP>Release at SD				
bdL	ON	Wait until scroll comes back to dSP	Press & Hold bdL>Release at ON				

ADVANCED PROGRAMMING				ADVANCED PROGRAMMING			
DISPLAY	SETTINGS	DESCRIPTION	ACTION WITH MAGNET				
Three Dashes		Scrolls through AP0 to AP5	Press & Hold at Three Dashes>Release at AP5				
Three Dashes		After Release three dashes appear again	Wait for PrA to Appear				
PrA		Indicates Advanced Programming	Wait for dLC to Appear				
dLC	15	Start Delay Programming	Press & Hold>Number Scrolls Up>Release at 15				
AHL	14.6	Set High Voltage Limit	Press & Hold>Voltage Scrolls Up>Release>Pause for AHL>Re-Touch>Voltage Scrolls Down>Release at 14.6V				
CL	14.5	Batt Temp Voltage Compensation Limit	Press & Hold>Voltage Scrolls Up>Release>Pause CL >Re-Touch>Voltage Scrolls Down>Release at 14.5V				
bu (bv)	14.2	Bulk Voltage Limit	Press & Hold>Voltage Scrolls Up>Release>Pause for Bv>Re-Touch>Voltage Scrolls Down>Release at 14.2V				
b1C	.2	Minimum Bulk Voltage Duration	Press & Hold>Duration Scrolls Up>Release, Pause for b1C>Re-Touch>Duration Scrolls Down>Release at .2 (12 Min)				
Au (Av)	14.1V	Absorption Voltage Limit	Press & Hold>Voltage Scrolls Up>Release>Pause for Av> Re-Touch>Voltage Scrolls Down>Release at 14.1V				
A1c	3.0	Minimum Absorption Voltage Duration	Press & Hold>Duration Scrolls Up>Release at 3.0 (3 Hours)				
Fu (Fv)	13.8V	Float Voltage Limit	Press & Hold>Voltage Scrolls Up>Release at 13.8V				
F1c	No Change	Min Float Voltage Duration	Press & Hold>Duration Scrolls Up>Release>Pause for F1c>Re-Touch>Duration Scrolls Down>Release at Desired Duration				
ALL	No Change	Low Voltage Alarm For Dash Lamp	Press & Hold>Voltage Scrolls Up>Release>Pause for ALL>Re-Touch>Voltage Scrolls Down>Release at Desired Voltage				
FbA	No Change	Field Threshold for Bv to Av Transition	Press & Hold>% Scrolls Down>Release>Pause for FbA>Re-Touch>% Scrolls Up>Release at Desired Percentage				
FfL	No Change	Field Threshold for Av to Fv Transition	Press & Hold>% Scrolls Down>Release>Pause for FfL>Re-Touch>% Scrolls Up>Release at Desired Percentage				
AL1	108	Max Alternator Temperature	Press & Hold>Temp Scrolls Down>Release>Pause for AL1>Re-Touch>Temp Scrolls Up>Release at 108 Celcius				
b1L	46	Battery Over Temp Limit	Press & Hold>Temp Scrolls Down>Release at 46 Celcius				
SLP	No Change	Battery Temp Compensation Slope	Press & Hold>Slope Scrolls Down>Release>Pause for SLP>Re-Touch>Slope Scrolls Up>Release at Desired Slope				